

User's Guide : Cartridges 50 ml PLASTIFORM®

• Before using PLASTIFORM® products :

1. Clean the part, to remove all impurities.
2. Use the Surface Cleaner DN1 to eliminate oils and greases.
3. Wait for the DN1 to dry (do not wipe).



• Installation :

1. Place the **Cartridge** into the **Dispensing Gun**
2. Remove the cap and attach a **Mixing Injector** to the front of the **Cartridge** (a quarter of a turn to the right).
3. *Optional for Fluid products* : reusable **Nozzle Tips** are available to pour the compound very precisely into holes, cavities and locations where access is difficult. Cut off the end of the **Nozzle** to increase the flow.

• Impression with a fluid product :

1. If the cartridge is new : Put aside the first sample of product that comes out of the **Injector**. It will be used as a sample test which will indicate when the product is cured.
2. Inject the compound into the part, and care that the **injector** remains immersed in the product. Slowly mix as you pour, and be careful not to create air bubbles.
3. Put a **Removal Ring** or **Plastin** around the extraction hole (to create a handle), and continue filling the part completely.
4. When the PLASTIFORM® is cured, take off the **Removal Ring** (or **Plastin**), and remove the impression without unscrewing!



• Impression with a pasty product :

1. If the cartridge is new : Put aside the first sample of product that comes out of the **Injector**. It will be used as a sample test which will indicate when the product is cured.
2. Apply the product on the surface of interest by exerting a pressure with the **Gun**, in order to avoid any bubbles on the final impression.
3. Wait for the time specified, then remove the impression.



• After using PLASTIFORM® :

1. Once the product is cured, remove the **Nozzle Tip** (if used). It can be re-used.
2. Remove the **Mixing Injector** and throw it with your regular waste.
3. Replace the cap on the **Cartridge**. You can keep and reuse the cartridge for at least 2 years.